

MINI KEYBOARD

Set Includes:


- 1 Extender Pipe
- 1 Lock Clamp
- 1 Wireless Joy Stick Keyboard with USB Receiver

Extender Pipe




Attaches to keyboard

Lock Clamp




Attaches to tripod


Mini Keyboard




1. Slip extender pipe through lock clamp to desired height and tighten.




2. Thread the keyboard onto the extender pipe, turning until you hear a few clicks and feel slight resistance. **Do Not Overtighten!** Finger-tight is sufficient. Tightening beyond this point may make removal difficult.



3. With the tripod on the floor place the opening of the "lock clamp" around the tripod and lock the clamp.



LOCK CLAMP INSTRUCTIONS




Open (Attach, Adjust or Remove)

Locked and Secure

To Remove the Keyboard from the Extender Pipe:

Hold the release button as shown while rotating the tray counter-clockwise. Be sure that the teeth of the latch mechanism remain disengaged while the tray is turning. If the tray does not rotate easily, please make sure your finger is correctly positioned on the latch button.



HOLD LATCH BUTTON AS SHOWN, WHILE ROTATING THE TRAY COUNTER-CLOCKWISE.

1-800-631-6989 • Fax: 1-800-631-2329
sales@pengad.com • www.pengad.com


Supplies for the Legal Professional