



TILT TRIPOD INSTRUCTIONS

TO POSITION LEGS

Gently push legs down until they click into position.




All three legs will move together




FLAT

Legs are almost flat to the floor.



NORMAL





HIGH

Highest position for standing.

TO TILT TRIPOD


Press release button with your toe and gently pull the writer forward. There are three degrees of tilt available. Choose the position that's most comfortable for you or vary the angle throughout the day.



To tilt the machine in the opposite direction (away from you) simply rotate machine 180 degrees on top key lock.

TO STRAIGHTEN TRIPOD

Press down on tip of leg with your foot while straightening machine back to the upright position.



1-800-631-6989 • Fax: 1-800-631-2329
e-mail: sales@pengad.com
www.pengad.com

Pengad Inc.
Supplies for the Legal Professional